

1- نوصّل كبل الشبكة بين الراوتر واللابتوب الموجود لدينا.



2- نقوم بفتح أي متصفح موجود على اللابتوب.



3- نقوم بادخال الـ IP التالي **192.168.1.1** في مربع البحث كما هو موضح في الصورة

ملاحظة : IP الدخول لاعدادات الراوتر يكون مكتوب على اللصاقة الموجودة خلف الراوتر



اضغط على نوع الراوتر الخاص بك





1- ضغط لاضافة الاعدادات

D-Link

Device Info
Advanced Setup
WAN
LAN
NAT
Security
Parental Control
Quality of Service
Routing

Wide Area Network (WAN) Setup
Choose Add, Edit, or Remove to configure WAN interfaces.
Choose Save/Reboot to apply the changes and reboot the system.

Port/Vpi/Vci	VLAN Mux	Con. ID	Category	Service	Interface	Protocol	Igmp	QoS	State	R
--------------	----------	---------	----------	---------	-----------	----------	------	-----	-------	---

[Add](#) [Remove](#) [Save/Reboot](#)

Device Info
Advanced Setup
WAN
LAN
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL

ATM PVC Configuration

This screen allows you to configure an ATM PVC identifier (PORT and VPI and VCI) at

PORT: [0-3]

VPI: [0-255]

VCI: [32-65535]

VLAN Mux - Enable Multiple Protocols Over a Single PVC

Service Category:

2- نملئ البيانات وفق الاتي

D-Link

Device Info
Advanced Setup
WAN
LAN
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL
Pptp
Interface Group

Connection Type
Select the type of network protocol for IP over Ethernet as WAN

PPP over ATM (PPPoA)

PPP over Ethernet (PPPoE)

MAC Encapsulation Routing (MER)

IP over ATM (IPoA)

Bridging

Encapsulation Mode

3- نقوم بالاختيار وفق الاتي

D-Link

Device Info
Advanced Setup
WAN
LAN
NAT
Security
Parental Control
Quality of Service
Routing
DNS
DSL
Pptp
Interface Group
IPSec
Certificate
Wireless
Diagnostics
Management

PPP Username and Password
PPP usually requires that you have a user name and password to establish your connection

PPP Username:

PPP Password:

PPPoE Service Name:

Authentication Method:

Dial on demand (with idle timeout timer)

MTU [1000-1500]:

PPP IP extension

Use Static IP Address

Retry PPP password on authentication error

Enable PPP Debug Mode

Enable KeepAlive

KeepAliveTime [0-30]: min

4- نقوم بادخال اسم المستخدم وكلمة المرور التي تم ارسالها من قبل المزود وفق الاتي





1- نضغط على الخيار التالي لبدء ضبط الاعدادات

DSL-224

SETUP ADVANCED MAINTENANCE STATUS

Wizard

Work

Internet Setup

Wireless Setup

Time and Date

SETTING UP YOUR INTERNET

There are two ways to set up your Internet connection. You can use the Web-based Internet Connection Setup Wizard or you can manually configure the connection.

Please make sure you have your ISP's connection settings first if you choose manual setup.

INTERNET CONNECTION WIZARD

You can use this wizard for assistance and quick connection of your new D-Link Router to the Internet. You will be presented with step-by-step instructions in order to get your Internet connection up and running. Click the button below to begin.

[Setup Wizard](#)

Note: Before launching the wizard, please ensure you have correctly followed the steps outlined

2- نقوم بإدخال البيانات وفق التالي

1 → 2 → STEP 3: SETUP INTERNET CONNECTION → 4 → 5

Please select your Country and ISP (Internet Service Provider) from the list below. If your Country or ISP is not in the list, please select "Others".

Country : Syria

Internet Service Provider : RUNNET

Connection Mode : ATM(ADSL)

Protocol : PPPoE

Connection Type : LLC

VPI : 8 (0-255)

VCI : 35 (32-65535)

IP Protocol : IPv4/IPv6

3- نقوم بإدخال اسم المستخدم وكلمة المرور التي تم ارسالها من قبل المزود

PPPoE

Please enter your Username and Password as provided by your ISP (Internet Service Provider). Please enter the information exactly as shown taking note of upper and lower cases. Click "Next" to continue.

Username : Ahmad22@runnet.sy

Password : كلمة المرور

Confirm Password : تأكيد كلمة المرور

4- نقوم بضبط شبكة WIFI وفق التالي

1 → 2 → 3 → STEP 4: CONFIGURE WIRELESS NETWORK → 5

Wireless Network Name (SSID) : اسم شبكة WIFI (1~32 characters)


Security Level :

None WEP WPA-PSK WPA2-PSK


WPA2 Pre-Shared Key : كلمة المرور لشبكة WIFI




1- نضغط على الخيار التالي للبدء بضبط الإعدادات



2- نقوم بإدخال البيانات وفق الاتي



3- نقوم بإدخال اسم المستخدم وكلمة المرور التي تم ارسالها من قبل المزود



4- نقوم بضبط شبكة WIFI وفق الاتي





D-Link

DSL-2750U // SETUP ADVANCED MANAGEMENT STATUS HELP

Wizard

SETTING UP YOUR INTERNET

You can set up the Internet connection through either of the two ways: Web-based InternetConnection Setup Wizard; Manual setup

For manual setup, you need to have the connection settings provided by your ISP.

INTERNET CONNECTION WIZARD

This wizard assists you to quickly connect the new router to the Internet, through step-by-step instructions. Click the button below to begin.

Setup Wizard

Note: Before launching the wizard, please ensure that you have correctly followed the steps outlined in the Quick Installation Guide corresponds to the router.

1- نضغط على الخيار التالي للبدء بضبط الإعدادات

STEP 2: SETUP INTERNET CONNECTION → 3 → 4 → 5

If you want to change WAN access type, you can click on "Ethernet" or "DSL".

note : If you select the WAN access type is "Ethernet", Please send line to LAN4 port!
When search available PVC, according to different condition, need the time is different!

WAN Access Type : Ethernet DSL

Please select your ISP (Internet Service Provider) from the list below.If your Country or ISP is not in the list, please select "Others".

Country : Syria

Internet Service Provider : RUNNET

Protocol : PPPoE

Encapsulation Mode: LLC

VPI : 8 (0-255)

VCI : 35 (32-65535)

2- نقوم بإدخال البيانات وفق الاتي

PPPOE PPPOA

Please enter the user name and password provided by your Internet service provider (ISP). Note that the information is case-sensitive. Click "Next" to continue.

Username : Ahmad22@runnet.sy

Password : كلمة المرور

Confirm Password : تأكيد كلمة المرور

3- نقوم بإدخال اسم المستخدم وكلمة المرور التي تم ارسالها من قبل المزود

Your wireless network is enabled by default. You can simply uncheck it to disable it and click "Next" to skip configuration of wireless network.

Enable Your Wireless Network

Your wireless network needs a name so it can be easily recognized by wireless clients. For security purposes, it is highly recommended to change the pre-configured network name.

Wireless Network Name (SSID) : WIFI شبكة اسم (1~32 characters)

Select "Visible" to publish your wireless network and SSID can be found by wireless clients, or select "Invisible" to hide your wireless network so that users need to manually enter SSID in order to connect to your wireless network.

Visibility Status : Visible Invisible

In order to protect your network from hackers and unauthorized users, it is highly recommended you choose one of the following wireless network security settings.

Security Level : None WEP WPA-PSK WPA2-PSK

Security Mode: WPA-PSK
Select this option if your wireless adapters support WPA-PSK.

Now, please enter your wireless security key.

WPA2 Pre-Shared Key : كلمة المرور لشبكة WIFI (8-63 characters, such as a~z, A~Z, or 0~9, i.e. '%Fortress123&')

Note: You will need to enter the same key here into your wireless clients in order to enable proper wireless connection.

4- نقوم بضبط شبكة WIFI وفق الاتي



ندخل اسم المستخدم admin وكلمة المرور تكون موجودة على اللصاقة الموجودة خلف الراوتر



1- نضغط على الخيار التالي

لبدء بضبط الاعدادات

2- نقوم بإدخال البيانات وفق الاتي

1 → 2 → **STEP 3: SETUP INTERNET CONNECTION** → 4 → 5

Please select your Country and ISP (Internet Service Provider) from the list below. If your Country or ISP is not in the list, please select "Others".

Country : Syria

Internet Service Provider : RUNNET

Connection Mode : ATM(ADSL)

Protocol : PPPoE

Connection Type : LLC

VPI : 8 (0-255)

VCI : 35 (32-65535)

IP Protocol : Ipv4/Ipv6

3- نقوم بإدخال اسم المستخدم وكلمة المرور التي تم ارسالها من قبل المزود

PPPoE

Please enter your Username and Password as provided by your ISP (Internet Service Provider). Please enter the information exactly as shown taking note of upper and lower cases. Click "Next" to continue.

Username : Ahmad22@runnet.sy

Password : كلمة المرور

Confirm Password : تأكيد كلمة المرور

1 → 2 → 3 → **STEP 4: CONFIGURE WIRELESS NETWORK** → 5

Wireless Network Name (SSID) : اسم شبكة WIFI (1~32 characters)

Security Level : None WEP WPA-PSK WPA2-PSK

WPA2 Pre-Shared Key : كلمة المرور لشبكة WIFI

4- نقوم بضبط شبكة WIFI وفق الاتي





WELCOME TO THE D-LINK SETUP WIZARD

This wizard will guide you through a step-by-step process to configure your new D-Link router and connect to the Internet.

- Step 1: Configure your Internet Connection
- Step 2: Configure your Wi-Fi Security
- Step 3: Set your Password
- Step 4: Select your Time Zone
- Step 5: Confirm Wi-Fi Settings

Cancel Next

1- نضغط على Next
للبدء بضبط
الاعدادات

2- نقوم بإدخال اسم المستخدم وكلمة المرور
التي تم ارسالها من قبل المزود



SET USERNAME AND PASSWORD CONNECTION (PPPOE)

To set up this connection you will need to have a Username and Password from your Internet Service Provider. If you do not have this information, please contact your ISP.

User Name : Ahmad22@runnet.sy

Password : كلمة المرور

Cancel Prev Next

3- نقوم بضبط شبكة WIFI وفق الاتي

STEP 2: CONFIGURE YOUR WI-FI SECURITY

Give your Wi-Fi network a name and a password. (2.4GHz Band)

Wi-Fi Network Name (SSID) :
اسم شبكة WIFI (Using up to 32 characters)

Wi-Fi Password :
كلمة المرور لشبكة WIFI (Between 8 and 63 characters)

Give your Wi-Fi network a name and a password. (5GHz Band)

Wi-Fi Network Name (SSID) :
اسم شبكة WIFI (Using up to 32 characters)

Wi-Fi Password :
كلمة المرور لشبكة WIFI (Between 8 and 63 characters)

Cancel Prev Next



في حال مواجهة أي مشكلة
يمكنك الاتصال بقسم خدمة العملاء

على الرياعي : 0112054